

CLAMP CODES

NOTE: OTHER CLAMP & COUPLING SIZES AND CONFIGURATIONS ARE AVAILABLE



Repair Clamp Codes	Description - 316 SS PN16 - 200 Long	DN SIZE
KCR-102B-085	080X200L CLAMP REPAIR 85-95 PN16 316SS	80
KCR-102B-095	080X200L CLAMP REPAIR 95-105 PN16 316SS	80
KCR-102B-100	100X200L CLAMP REPAIR 100-110 PN16 316SS	100
KCR-102B-110	100X200L CLAMP REPAIR 110-120 PN16 316SS	100
KCR-102B-114	100X200L CLAMP REPAIR 114-124 PN16 316SS	100
KCR-102B-120	100X200L CLAMP REPAIR 120-130 PN16 316SS	100
KCR-102B-130	100X200L CLAMP REPAIR 130-140 PN16 316SS	100
KCR-102B-140	100X200L CLAMP REPAIR 140-150 PN16 316SS	100
KCR-102B-150	150X200L CLAMP REPAIR 150-160 PN16 316SS	150
KCR-102B-160	150X200L CLAMP REPAIR 160-170 PN16 316SS	150
KCR-102B-175	150X200L CLAMP REPAIR 175-185 PN16 316SS	150
KCR-102B-190	150X200L CLAMP REPAIR 190-200 PN16 316SS	150
KCR-102B-200	200X200L CLAMP REPAIR 200-210 PN16 316SS	200
KCR-102B-210	200X200L CLAMP REPAIR 210-220 PN16 316SS	200
KCR-102B-215	200X200L CLAMP REPAIR 215-225 PN16 316SS	200
KCR-102B-220	200X200L CLAMP REPAIR 220-230 PN16 316SS	200
KCR-102B-230	200X200L CLAMP REPAIR 230-240 PN16 316SS	200